

Installation

Mounting Flush Back boxes to Plaster board covered walls.

Very Important

Back Box must be mounted flush with the finished surface.

If back box is set too deep, M3 studs will not reach rubber sockets to hold panel correctly.

If back box is set too high, then the panel sits with an untidy gap between foam rubber seal and wall surface.

Intercom Station overlaps back box by just 4mm. So very it is important to fit back box, so there is a very small gap between back box and wall covering.

Stations should not be mounted back to back on the same wall, they should be mounted at least 1 metre apart and more if possible.

