

Installation

Mounting Flush Back boxes to Plaster board covered walls.

Very Important

Back Box must be mounted flush with the finished surface.

If back box is set to deep, M3 studs will not reach rubber sockets to hold panel correctly.

If back box is set to high, then the panel sit with an untidy gap between foam rubber seal and wall surface.

Intercom Station overlaps back box by just 4mm. So very it is important fit back box, so there a very small gap between back box and wall covering.

Stations should not be mounted back to Back on the same wall, they should be mounted at least 1 metre apart and more if possible.

